CABINET PARTS

REFRIGERATOR

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00

(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		LITERATURE PARTS
	LIT2255705	Use & Care Guide
	LIT2255774	Service & Wiring Sheet
	LIT2261181	Energy Guide
	LIT2220407	Modular Icemaker Service Sheet
2	2174748	Front Roller (2)
3	3400517	Screw
4	2196236	Roller (Rear) (2)
5	489427	Screw
6	2155013	Clip, Grille
7	489478	Screw
8	2186443	Housing, Water Filter
9	2209697	Shim
10	2203770	Hinge Top, FC
11	2203771	Hinge Top, RC
12	3400113	Screw
13		Hinge Cover, FC
	2203407W	White
	2203407T	Biscuit
	2203407B	Black
14	2217075	Hinge Bottom (2)
15		Filler, Wrapper
	2196094	White
	2196150	Biscuit
	2196097	Black
16		Grille
	2198467W	White
	2198467T	Biscuit
	2198467B	Black
17	489497	Screw
18	489464	Screw
19	940139	Drain Fitting
20	1108438	Extension Tube
21	1108439	Clip, Drain Tube
22	2255518	Water Filter
23	2204202	Cover, Unit
24		Hinge Cover, RC
	2203408W	White
	2203408T	Biscuit
	2203408B	Black
25	549193	Clamp, Service Cord
26	489084	Screw
27	2155311	Door Closer, Lower Cam (2)
28	489483	Screw
29	489500	Screw
30		Cap, Water Filter
	2186494W	White
	2186494T	Biscuit
	2186494B	Black
31		Cabinet (Not A Serviceable Part
32	8281227	Screw
33	3400103	Screw

REFRIGERATOR LINER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Serviceable Part)
2	2194744	Escutcheon, Meat Pan Control
3	2182757	Slide Meat Pan Control
4	2182147	Louver
5	1118894	Switch, Rocker Arm
7	2256035	Bracket, Dual Crisper
8	2256037	Wire Harness, Dual Crisper
9	2206270	Shelf Ladder
10	487539	Screw
12	2205813	Strap
15	2209753	Air Diffuser Assembly
18	2162085	Socket
19	2256126	Reservoir
20	2255743	Light Bulb
21	2209769	Light Lens
22	488280	Screw
23	2196485	Stud Assembly
24	3400894	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR SHELF PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2194736	Shelf
2	2174150	Glass, Cover
3	2209698	Cover, Crisper
4	2255593	Trim, Handle
5	2179259	Glass, Cover
6	2179350	Deflector
7	2255592	Trim, Handle
8	2217039	Cover, Meat Pan
9	2179342	Slide, Humidity Control
10	2188652	Crisper Pan
11	2188654	Meat Pan
13	2179243	Trim, Handle
14	2179343	Body, Humidity Control
15	2206347	Shelf, Snack Bin
16	2195975	Frame, Shelf
18	2188655	Snack Pan

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER LINER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Liner (Not A Seviceable Part)
7		Track, Basket−Dual
	2223706	Right
	2223707	Left
9	2211743	Shelf, Slide Out
10	2223582	Basket, Tall
12	2195904	Basket Front
13		Shelf Track
	2223705	Right Side
	2223704	Left Side
14	2212343	Shelf
15	2223278	Basket, Slope
16	486298	Screw
17	842534	Clip, Air Duct
19	2255572	Cover, Emitter
21	487539	Screw
22	2198635	Spring
23	2198634	Pin
25	1115373	Switch, Rocker Arm
26	2220398	P.C. Board Emitter
27	2255589	Cover, Ice Maker
28	2212321	Slide, Ice Maker
29	489478	Screw
30	489214	Screw
32	2162085	Light Socket
33	2255743	Light Bulb
34	8281185	Screw
35	2198633	Flipper
36	2255558	Cover, Receiver
37	2255562	Slide, Ice Maker Shut Off
38	2255114	P.C. Board, Receiver
39	2198643	Lens
41	2212376	Light Lens
42	2198641	Bracket, Ice Maker Cover
43	2155597	Socket, Light
45		Ladder
	2212315	Left Side
	2212316	Right Side
46	2219878	Shield, Wiring

MOTOR AND ICE CONTAINER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00

(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MOTOR AND ICE CONTAINER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	2212302	Ice Bin
2	2255577	Crusher Bin
3	2212342	Auger
4	2212382	Blade, Stirring
5	1119007	Spacer, Flat
6	2255461	Cover, Crusher
7	1119013	Blade, Rotary
8	1119005	Spacer, Step
9	2198601	Blade, Fixed
10	1119012	Blade, Rotary
11	2198602	Block, Blade
12	489229	Roll Pin
13	1119006	Blade, Rotary
14	489235	Washer, Plain
15	2198661	Washer, Coupling
16	2220457	Coupling
17	8281164	Screw
18	3400065	Screw
20	2255578	Latch, Bin
21	2198608	Spring, Latch
23	8281163	Screw
24	2212369	Holder
25	2220458	Coupling, Bottom
26	2198628	Seal
27	2212370	Washer
29	2198607	Spring
30	999536	Drive Shaft
31	2212304	Enclosure, Motor
32	2212363	Dispenser, Motor
33	2212305	Cover
35	489478	Screw
36	2212365	Sleeve, Coupling

REFRIGERATOR DOOR PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

REFRIGERATOR DOOR PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Refrigerator Door (Includes Item #8)
	2206716W	White
	2206716T	Biscuit
	2206716B	Black
2	2256101	Door Compartment
4	2156022	Trivet
5	489491	Screw
6	2179607	Door Bin (3)
7		Extension, Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
8		Door Gasket, Magnetic
	2221300	Mist Beige
	2221311	Black
9		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
10	3400012	Screw
11	2195327	Clip (2)
12	2255121	Nameplate
13		Extension, Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
14	2182178	Door Closer, Upper Cam
15	489420	Screw
16		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
17	2182180	Thimble, Top
20	3400852	Screw

FREEZER DOOR PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

FREEZER DOOR PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Freezer Door (Includes Item #8 And Dispenser Front Parts)
	2261179W	White
	2261179T	Biscuit
	2261179B	Black
2		Handle, Center
	2186649W	White
	2186649T	Biscuit
	2186649B	Black
3	488500	Screw
4	489491	Screw
5	2195327	Clip (2)
6	2156021	Trivet
8		Door Gasket, Magnetic
	2221301	Mist Beige
	2221312	Black
9	2212375	Trim, Door Shelf
10	3400012	Screw
11	2207225	Wire Harness
12	2182179	Door Closer, Upper Cam
13	489420	Screw
14		Bracket, Door Stop
	2206629	Chrome
	2206629B	Black
15	2223472	Trivet, Tilt Out (2)
16	2154473	Connector
17		Extension, Bottom
	2194969W	White
	2194969T	Biscuit
	2194969B	Black
18		Extension, Top
	2194971W	White
	2194971T	Biscuit
	2194971B	Black
19	2182181	Thimble, Top
20	2223473	Basket, Tilt Out (2)
21	3400852	Screw

DISPENSER FRONT PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DISPENSER FRONT PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Housing, Dispenser (Not Serviced)
2	3196537	Screw
3	2194719	Retainer, Levers
4	2180209	Spring, Torsion
5	2196195	Pin
6	2180352	Door, Ice
7	2206423	Door Mechanism Assembly
8	2205686	Mechanism Delay
9		Grille, Overflow
	2206671W	White
	2206671T	Biscuit
	2206671B	Black
10	2209718	Water Fitting Assembly (Includes Water Tube)
11		Lever, Ice Dispenser
	2255431W	White
	2255431T	Biscuit
	2255431B	Black
12	2180224	Guide, Ice
13	2180200	Lamp Holder
14	2162361	Switch (2)
15	2183771	Bracket, Control
16	3406124	Bulb, Light
17		Lever, Water Dispenser
	2255432W	White
	2255432T	Biscuit
	2255432B	Black
18		Switch Assembly (Not Available Order #23)
19		Overlay, Front Cover (Not Available Order #23)
20	2187406	Wire Assembly
21		Front Cover, Housing (Not Available, Order #23)
22	489000	Screw
23		Front Cover Assembly (Includes Items 18, 19, 20 & 21)
	2261177W	White
	2261177T	Biscuit
	2261177B	Black
24	625834	Spacer, Switch (2)
25	2195051	Strain Relief
26	987121	Shield, Ice Door

UNIT PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UNIT PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	486692	Speed Nut
2	2190685	Fan, Blade
3	2204484	Condenser Assembly
4	489464	Screw
5	2216914	Clip, Condenser
6	1115374	Clip, Wiring
7	2149293	Heat Shield And Drain Pan
8	2205764	Tube Suction
9	8281232	Screw
10	2255798	Tube, Condenser to Heat Loop
12	4387731	Cover (Service Compressor Only)
13	4387767	Overload (Service Compressor Only − Includes Relay)
14	2161324	Clip, Defrost Heater
16	2220474	Start−Device, Combination (Start Relay and Overload for Production Compressor Only)
17	999532	Capacitor (Production)
	4387764	(Service)
20	2182057	Unit Cover, Bottom
21	489396	Clip
22	2164518	Evaporator
23	2216997	Bracket, Insert
24	2206005	Motor, Fan
25	1105523	Tray, Evaporator
26	2187733	Harness, Unit
27	2199167	Drier
28	2212191	Compressor (Includes Items 12, 13, 17 & 27)
29	2255239	Electronic Control
30	2160501	Frame, Unit Mounting
31	2255623	Control Box
32	2181929	Bracket, Fan Motor
33	2188174	Heater, Defrost
34	2161330	Clip
35	2196155	Bi−Metal, Defrost
36	2255624	Cover
37	489473	Screw
38	2223314	Clip, Retaining
39		Grommet (4)
	2183042	(Production)
	4387558	(Service)
40	489340	Screw
41	2196202	Air Baffle
42	2155547	Clip, Heat
48	2149718	Unit Mounting Rail
49	8281160	Screw
50	2186496	Guard, Fan
51	2161302	Sleeve
53	489427	Screw
55	489478	Screw
59	2208280	Clip, Wire & Tube
63	2209709	Connector, Water Tube

Following Parts Not Illustrated and Optional Parts Not Included

978025	Valve, Access (1/4")
978026	Valve, Access (5/16")
978027	Valve, Access (3/8")
978028	Valve, Access (1/2")
978029	Valve, Access (5/8")
978030	Valve, Access (3/4")
876764	Valve, Access (3/16")

REFRIGERANT CHARGE

5.0 oz.
(R−134)

ICEMAKER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

ICEMAKER PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
2	2198578	Fitting, Water Tube
4	2255012	Tube, Filter Outlet
5	628379	Clip, Fuse
6	2198677	Connector, Water Tube
7	2216964	Tube, Water
9	489478	Screw
10	2188623	Valve, Solenoid
12	2200202	Tube, Filter Inlet
16	489385	Clamp, Tube
18	2174358	Cover
19	488649	Screw
20	2212351	Mold & Heater Assembly (Also Order 542638 Silicone Grease)
22	628356	Cup−Water Fill
23	2212320	Ejector
24	2212318	Ice Striper
25	2194712	Support
26	627796	Retainer, Thermostat
27	627985	Thermostat (Also Order 542369 Cement Alumilastic)
28	8533917	Screw
30	489276	Screw
32	2187484	Harness, Wiring
33	2212317	Bracket, Icemaker Mounting
35	628399	Module Assembly (Includes Items 37 & 38)
37	628398	Motor
38	489136	Screw
100	2212353	Icemaker Assembly

CONTROL PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2255222	Control Box
2	2255991	Shield
3	3196537	Screw (4)
4	3400972	Washer
6	2255229	Electronic Control
8	940014	Hole Plug
9	2261232	Shield, Electrical
10	2261231	Shield, Electrical
11	2255226	Cam Assembly
12	2255413	Bearing Body
13	2255225	Light Lens
15	2255227	Pivot Arm
16	627068	Screw
17	2162085	Light Socket
19	2255743	Light Bulb
20	2255235	Control Box Harness
22	2255666	Shield, Heat
23	2255228	Connecting Rod
24	489285	Fastener, Push−On
25	2261334	Escutcheon, Control Box
26	2255232	Knob, RC
27	2255992	Knob, FC
28	2216113	Thermistor
29	489203	Spring Washer
31	2261265	Air Seal, Thermistor
33	3400971	Nut, Hex

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AIR FLOW PARTS

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	2182119	Fan Scroll
2	2155590	Retainer, Fan Motor
3	2198595	Air Scoop
4	2212377	Air Duct, Upper
5	2261329	Foam, Shield
5	2212313	Air Duct Freezer
7	2162404	Fan Motor
8	2169142	Fan Blade
10	2176759	Fan Grommet (2)
12	2206504	Harness, Fan Evaporator, And Heater, Bi−Metal
13	2155788	Gasket Cover
14	2172840	Wire Tie
16	2203875	Gasket
17	2212314	Cover, Evaporator
18	489355	Screw
21	489478	Screw
22	2203595	Support, R.S
23	2203596	Support, L.S

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

PARTS NOT ILLUSTRATED

For Models: ED2LHAXMQ00, ED2LHAXMT00, ED2LHAXMB00
(White) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Parts Not Illustrated and Optional Parts (Not Included)

Customer Touch−Up Material

	*350942	Primer, White (12 Oz. Spray Can)
	*350939	Enamel, Black (12 Oz. Spray Can)
	*350930	Enamel, White (12 Oz. Spray Can)
	*350956	Enamel, Almond (12 Oz. Spray Can)
	*4392901	Enamel, Biscuit (12 oz. Spray Can)
	72017	Brush Touch−Up Kit (White)
	72107	Brush Touch−Up Kit (Almond)
	72032	Brush Touch−up kit (Black)
	4392899	Brush Touch−Up Kit (Biscuit)

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

Miscellaneous

	212643	Sealer, Gum (4 Feet)
	479502	Tape, Vinyl (3/4 x 108")
	876370	Kit, Insulation (2 Pcs. x 3" x 24" X 48")
	876305	Kit, Insulation (14 Pcs. x 3" x 24" x 48")
	978941	Insulation, Fiberglass (63−1/2" x 35−1/2" X 2−5/8)
	876029	Kit, Foam Slab (30" x 32−1/2" x 1−1/2")
	505587	Sealer, Mastic (1 Qt.)
	503695	Cork, Sealer (1/4 Pound)
	511873	Touch−Up, White Porcelain (2 Oz.)
	542638	Grease, Silicone (1/2 Oz.)
	542639	Cement, Alumilastic (1−1/4 Oz.)
	606755	Bag, Insulation (36−5/8" x 46")
	799833	Kit, Evaporator Repair (Aluminum Epoxy)
	833938	Kit, Terminal Connector
	2255576	Ice Container Assembly

Refinishing Material

	799340	Enamel, Black (1 Qt. Uncut)
	799344	Enamel, White (1 Qt. Uncut)
	978883	Enamel, Almond (1 Qt. Uncut)
	4392900	Enamel, Biscuit (1Qt. Uncut)

TORX SCREW WRENCH

	1117510	Torx Key